- 1. Unplug the power
- 2. Press and Hold the Mode Button on front of switch
- 3. Plug the power back in again, release when SYST LED blinks amber and green for some time...
- 4. flash init
- 5. load_helper
- 6. dir flash:
- 7. rename flash:config.text flash:config.old
- 8. boot
- 9. n (no user mode)
- 10. enable
- 11. rename flash:config.old flash:config.text
- 12. copy flash.config.text system:running-config (get error opening flash.config.text, no worries)
- 13. configure terminal
- 14. enable secret "new password"
- 15. exit
- 16. copy r s
- 17. reload

nErase VLAN (except VLAN1, native) and Startup-Config (reset switch conf)

- 18. delete flash:vlan.dat
- 19. erase startup-config
- 20. reload